

**UNI-COM**

**Sensor light**

**Model: 62875**

## **Operating instructions**

### **Battery installation and replacement**

1. Remove the back of the light by turning anti-clockwise.
2. Insert 3 x AAA batteries, observing the polarity markings.
3. Refit the back of the light.

Important - when new batteries are installed the light will turn on, it will turn off automatically after 30 seconds.

### **Directions for use**

The light will automatically turn on when movement is detected up to 1.5 metres away in the dark. The light will remain on for approximately 15 seconds after the last movement is detected.

#### **Safety warning**

Keep out of reach of children. Remove the batteries if the light is not going to be used for an extended period. Do not mix new and used batteries. Do not mix different types of batteries. Exhausted batteries should be removed immediately. Failure to follow these safety instructions could result in fire, electric shock, injury or damage to persons, product or property and will invalidate the guarantee.

#### **Guarantee**

This product is guaranteed for one year from the date of purchase against faulty parts or workmanship. It does not cover batteries or physical damage to the units. Proof of purchase required. This does not affect your statutory rights.

#### **Guarantee**



This product uses 3 x AAA batteries.  
They should be removed prior to disposal.

V1  
Made in China



#### **Uni-Com**

Long Reach, Galleon Boulevard, Crossways Business Park,  
Dartford, Kent, DA2 6QE, United Kingdom

Email: [info@uni-com.co.uk](mailto:info@uni-com.co.uk)

Web: [www.uni-com.co.uk](http://www.uni-com.co.uk)