

SPECIFICATION	TROUBLESHOOTING	TROUBLESHOOTING cont.	SAFETY WARNING	UNI-COM
Power supply: 3 x AA batteries Type R2 device	Adding extra chime units All wireless + Uni-Com door chimes work together and you can add unlimited chime units to your set up. To add an extra chime unit repeat the pairing procedure with the new chime unit. Adding extra bell pushes	Chime doesn't sound when bell push is pressed Does the blue LED bell push indicator light illuminate when it is pressed? If NO: 1. Check the bell push battery to ensure has been installed correctly.	Chime unit is for indoor use only. The bell push is weather resistant, do not submerge. If cleaning of the chime unit is required, remove from the mains power and wipe unit with a dry cloth. Do not use if casing of the chime unit becomes cracked or damaged. Exhaused batteries must be removed immediately. Failure to follow these instructions could result in fire, electric shock, injury or damage to persons, product or property and will invalidate the guarantee.	Portable door chime Model: 68426
Power supply: 1 x CR2032 button cell battery Frequency: 433.92MHz Operating temp: -5°C to 55°C Standby power consumption: <5μA	A wireless + bell push will work with all wireless + door chimes. A maximum of 8 bell pushes can be paired to the same chime unit. To add an extra bell push repeat the pairing procedure with the new bell push. Chime sounds when nobody is pressing the bell push Your chime unit may be picking up outside interference from other wireless transmitters.	 Replace the bell push battery. If YES: Replace the batteries in the chime unit. The chime unit may not be receiving signal from the bell push. Move the chime unit closer to the bell push. The chime unit may be picking up outside interference from other wireless transmitters. Clear the chime unit memory and repeat the 	Description Description Keep out of Reach of childnem Swallowing can lead to chemical burns, perforation of soft tissue and death. Seven burns can occur within 2 hours of ingestion. Seek immediate medical attention. Seek immediate medical attention. Batteries Guarantee	Uni-Com Authorised Representative Long Reach, Galleon Boulevard, Tucks O'Brien, 24 Magna Drive,
Hereby Uni-Com delcares that the radio equipment type door chime is in compliance with Radio Equipment Regulations 2017 (SI 2017/1206) and Directive 2014/53/EU. The full text of the UKCA Declaration of Conformity is available to view at www.uni-com.co.uk	Clear the chime unit memory by pressing and holding the chime selection button for 20 seconds until a "Ding Dong" sound is heard. Repeat the pairing procedure.	pairing procedure.	The bell push uses 1 x CR2032 button cell battery. It shoud be removed prior to disposal. Help the environment by disposing of your products and batteries responsibly.	Crossways Business Park, Magna Business Park, Dartford, Kent, DA2 6QE, Citywest Road, Dublin 24, United Kingdom D24 FNYO, Ireland Email: info@uni-com.co.uk Web: www.uni-com.co.uk
6	7	8	9	©2024 Uni-Com. All rights reserved. V2