

Operating Instructions – 24 Hour Segment Timer

Setting the On/Off Periods:

The timer can be used to set up to 48 on/off periods a day. To set the required “On” periods, using your finger, a pen, or screwdriver, push down all the segments required. Each segment represents 15 minutes.

Setting the Time:

Turn the dial clockwise until the time indicator arrow is pointing towards the correct time.

Manual On:

The pre-set On/Off periods can be interrupted by using the switch on the side of the timer which allows you to switch the connected appliance ON permanently without affecting the pre-programmed settings. Push the switch up to the On position I.

Pushing the switch back down allows the Timer to continue with the pre-programmed settings once more.

Connection:

Once the required on/off periods and the correct time have been set, plug the Timer into a suitable wall socket (check that the socket switch is in the off position), then plug the appliance into the Timer socket. Turn the wall socket and the appliance on.

The Timer will now start to operate and switch the appliance on and off according to the position of the segments.

Specification:

Supply:	AC230V~ 50Hz
Capacity	13A Resistive load 2A inductive
Min Temp:	0 °C
Max Temp:	+40 °C

This Timer meets current electrical safety regulations.

Precautions:

For indoor use only.

Do not plug in any appliance that exceeds the capacity of the Timer.

Always ensure that the plug of any appliance is fully inserted into the Timer socket.

To clean the Timer, switch off and remove from the wall socket and wipe with a dry cloth.

Do not immerse in water or any other liquid.

Fan heaters and heaters with exposed elements should not be left unattended, these types of appliances should not be connected to Timers.

Do not connect Timer to a device performing a mechanical function.

Not recommended for use with extension leads.

Not recommended for use with immersion heaters.

Warranty: This unit is guaranteed against faulty parts or workmanship for a period of one year from date of purchase. The guarantee does not cover batteries, damage caused by battery leakage, damage caused by incorrect installation, or physical damage to the casing.

The guarantee does not affect your statutory rights.

Uni-Com (Global) Ltd
1 & 2 Enterprise Way
Edenbridge
Kent
TN8 6EW

Made in China

TE-10 / 55297